



# Nintendo 3DS Back Cover Replacement

Back cover removal.

Written By: David Hodson



## INTRODUCTION

Removing the back cover to access the battery and internals of the Nintendo 3DS.

---




### TOOLS:


- [Phillips #00 Screwdriver](#) (1)
-

## Step 1 — Back Cover



- Unscrew the four Phillips #00 screws along the top of the back cover.

 The screws are held in place by locking washers, and will not come out of the back cover.

 The comments section is full of unlucky souls who will tell you that the screws here through step 4 will strip incredibly easily. Press down fairly hard, and go slow.

## Step 2



- ① Hold the device in one hand and turn it over.
  - Grab the top edge of the back cover with your opposite hand so that the cover does not fall back into place.
- ① Flip the 3DS over again so that the back cover is facing up.
  - Pull the back cover up and away from the rest of the device to remove it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 06:08:51 AM.